

[Revised: Water inlet valve] Replacement instruction for WM-0460/0460-22/0680/1100

1st Step: Remove all 6 screws on inlet water line fitting and pull the water inlet valve assembly out the side of the machine for all models.



2nd Step: Disconnect the 3/8" adapter from the J.G. fitting and remove the water inlet valve assembly.

3rd Step: Please follow the instruction depending on the models.

1) Models: WM-0460-AC/AH, WM-0680-AC/AH

Insert the new [Water Inlet Hose ASSY \(code # 4690-02820\)](#) through the back of the machine and fasten with the two screws (top and bottom) removed earlier.



2) Models: WM-0460-AC/AH-22

Replace to both new [Water Inlet Valve \(code #3400-27500\)](#) and [Main Board V7.0 \(code #4150-08807\)](#)

3) Models: WM-1100-AC/AH

Remove old water inlet valve and go to 4th Step (Don't need any part to replace).

4th Step: Secure J.G. fitting & water line, check for leaks.