



SSI-143S


Revised Mar, 2020




No	Part name	Description	Part code
1	DRAIN BOX UP	SPLASH GUARD	336008600
2	DRAIN BOX	DRAIN TRAY	336008400
3	FOOT CASTER	STAND OFF	443047100
-	CASTER BOLT TYPE	WHEEL	218002300
4	FILTER CONDENSOR	FILTER	640005800
5	GRIP HANDLE	[SET 5/5-1] HOPPER LID HANDLE (OLD)	342001900
5-1	BOLT COVER POM	[SET 5/5-1] HOPPER LID BOLT (OLD)	214014800
6	GASKET FOOD PAN (OLD)	GASKET	656000900
7	COVER FOOD PAN (OLD)	HOPPER LID (OLD)	308002400
8	COVER BASKET (NEW)	HOPPER LID (NEW)	317140700
-	BRUSH 3	BRUSH 3	388001000
-	BRUSH DRUM	BRUSH DRUM	388001300




No	Part name	Description	Part code
1	DASHER COVER STAR	DASHER COVER STAR	317099701
-	STAR MADE	STAR MADE	388001400
-	DASHER COVER MOUNT	DASHER COVER MOUNT	317072600
2	MIXING SHAFT	MIXING SHAFT	314015601
3	AL LEVER	DRAW HANDLE w/ GRIP	309001900
13	GRIP HAND	DRAW HANDLE GRIP	342001400
3-1	SCREW ADJUST	[SET 3-1/3-2/3-3] DISPENSING CONTROL	210806100
3-2	ADJUST NUT	[SET 3-1/3-2/3-3] DISPENSING CONTROL NUT	215011000
3-3	O-RING SCREW ADJUST	[SET 3-1/3-2/3-3] DISPENSING CONTROL O-RING	303017700
4	SHAFT DASHER 143 MIDDLE	[SET 4/4-1] PLUNGER MIDDLE	314009600
4-1	PISTON PIN	[SET 4/4-1] PLUNGER PIN	315002900
5	SHAFT DASHER 143	[SET 5/5-1] PLUNGER SIDE	314031400
5-1	PISTON PIN	[SET 5/5-1] PLUNGER PIN	315002900
6	O-RING LEVER SHAFT	HANDLE SHAFT O-RING	303020000
-	LEVER SPRING	PLUNGER SPRING	323002500
7	PATITION FOOD	O-RING MIDDLE	392000300
8	DASHER COVER PACKING	DASHER COVER O-RING (NEW)	303018100
	DASHER COVER PACKING	DASHER COVER O-RING (OLD)	303017300
9	DASHER LEVER SHAFT	DASHER HANDLE SHAFT	314012201
10	PACKING PISTON	O-RING SIDE	303014700
11	HANDLE GRIP 181	DASHER COVER BOLT	342004100
12	DASHER ASSY	DASHER	403014100
14	PACKING JAVARA	BOOT SEAL	303017200
15	DASHER LUG POM	BLADE (NEW)	403015000
	DASHER LUG POM	BLADE (OLD LONG)	343000600
	DASHER LUG POM	BLADE (OLD SHORT)	343000500
16	BEARING DASHER	DASHER BEARING	310003500




No	Part name	Description	Part code
1	CARBURETOR ADJUST	[SET 1/2] CARBURETOR TUBE (OLD #234003101)	234003800
2	CARBURETOR TUBE BODY	[SET 1/2] CARBURETOR TUBE SLEEVE (OLD #234000501)	234003700
-	PACKING CARBURETOR	CARBURATOR RING	303014600
3	SHAFT CONECTOR 143	[SET 3/12/12-1] SHAFT CONECTOR	314010800
12	KEY	[SET 3/12/12-1] KEY (SHORT)	219001800
12-1	SET BOLT	[SET 3/12/12-1] BOLT	214020100
6	BEARING DRUM	[SET 4/5/6/14] DRUM BEARING	310002100
4	RING BEARING SHAFT	[SET 4/5/6/14] DRUM BEARING RING	232002400
14	STOPPER BEARING DRUM	[SET 4/5/6/14] DRUM BEARING STOPPER	398007800
5	NUT BEARING DRUM	[SET 4/5/6/14] DRUM BEARING NUT	327007300
8	V-BELT	V-BELT (A-38)	305002600
9	BELT PULLY TOP	BELT PULLY TOP	307003400
10	GEARED MOTOR	GEAR MOTOR	353022301
7	BELT PULLY DOWN	[SET 7/11] BELT PULLY BOTTOM	307003600
11	KEY (LONG)	[SET 7/11] KEY (LONG)	219003700
13	RING OIL	RING OIL	232001900
15	SPRING VIBRATION FRONT	SPRING VIBRATION FRONT	323003400
16	MOTOR FOOT RUBBER	MOTOR FOOT RUBBER	353008200
-	CAPACITOR (125VAC,200μF)	MOTOR START CAPACITOR (200uF)	387001500
-	CAPACITOR (250VAC,30μF)	MOTOR RUN CAPACITOR (30uF)	387001600
-	SPARK KILLER	SPARK KILLER	387000600
-	THERMAL SENSOR CYLINDER	FREEZER THERMAL SENSOR	317075102
-	THERMAL SENSOR MIX	HOPPER THERMAL SENSOR	317101901
17	SENSOR POST	[SET 17~21, H1] MIX LOW SENSOR ASSY	470000600
18	SENSOR RING		
19	SENSOR POLE		
20	SENSOR PACKING		
21	PACKING SENSOR (B)		
H1	MIX LOW SENSOR HARNESS	[SET 17~21, H1] HARNESS	377038500
22	DASHER MOTOR	DASHER MOTOR	353014700



No	Part name	Description	Part code
1	FAN MOTOR	FAN MOTOR	353020901
2	FAN	FAN	308001800
2-1	FAN GUARD	FAN GUARD	308001200
3	CONDENSER ASSY	CONDENSER ASSY	411008301
4	CAPILLARY 09200	CAPILLARY	325000300
5	FILTER DRYER	HOPPER DRYER	372002701
6	FILTER DRYER	FILTER DRYER	372001600
7	EXPANSION VALVE	EXPANSION VALVE	340013200
8	E.P.R	E.P.R	523000300
9	HIGH PRESSURE SWITCH	HIGH PRESSURE SWITCH	355007700
10	COMP/NT2180GK (220V/60HZ)	FREEZER COMPRESSOR	394010400
10-1	ASSY CSR BOX (FREEZER/NT2180GK)	FREEZER COMPRESSOR STARTER KIT	426058900
11	COMP FOR HOPPER	HOPPER COMPRESSOR	394008800
11-1	START-RELAY	START-RELAY	357009700
11-2	START CAPACITOR	START CAPACITOR	659007700
11-3	OLP	OLP	658001100



No	Part name	Description	Part code
1	CONTROL PCB	CONTROL PCB	367002900
2	MAGNET	MAGNETIC CONTACTOR COMPRESSOR	322003800
3	MAGNET	MAGNETIC CONTACTOR MOTOR	322002300
4	RELAY	RELAY	602000500
5	EMPR	EMPR	356000600
6	TERMINAL BLOCK	TERMINAL BLOCK (6)	363004300
-	ELECTRONIC CENTRIFUGAL SWITCH	CENTRIFUGAL SWITCH	322004500
-	DMR	DMR	602000300



No	Part name	Description	Part code
1	MICRO S/W	MICRO SWITCH	355008200
2	BUTTON DISPLAY	BUTTON DISPLAY	440013400
3	LEVER SHAFT	LEVER SHAFT	425000300
4	BUTTON PCB	BUTTON PCB	367004600
5	MAIN PCB	MAIN PCB	415002804